## WH, WS & WS-J Repair Rework Polish bore of shaft until groove is removed; if bore is larger than $\emptyset$ .444", recommend replacing shaft. If larger than $\emptyset$ .448", replace shaft. There may be some pitting in bore of shaft; some small pits are okay and do not have to be removed by polishing. Inspect for groove in seal bore of shaft WH 001 Shaft Ø.444" The WS 001 shaft has Ø.377" bore; replace shaft if worn beyond Ø.386". WS 001 Shaft Ø.382" Inspect face of Inlet Nut for pitting, erosion, or dings .51" MIN .75" MIN .69" MIN **REPLACE** REPLACE **REPLACE** IF LESS IF LESS IF LESS **≪** .63" ➤ 1. Indicate in on shoulder .38" of nut to within .001"

-2. Machine this face to 32 finish or better; enough to remove all pitting or other damage. Typically .020" or less. Keep track of how much is removed.

3. Machine same amount

off of these faces

.48'

WH 002

**Inlet Nut** 



**WS 202** 

Face

.38"

**WS 002** 

**Inlet Nut**